

# Tips for thermoforming

## Eastar™ 6763 copolyester and Eastman Tritan™ MP100 copolyester—Extruded sheet

Sheet extruded from Eastar™ 6763 copolyester and Eastman Tritan™ MP100 copolyester is easy to thermoform. This brochure lists some helpful tips in processing Eastar and Tritan.

### Mold design

Eastar 6763 and Tritan MP100 can be used successfully with male molds, but female molds are recommended. Thermoformed parts made with female molds will have more consistent flange thicknesses, easier part removal, and reduced bridging (i.e., webbing) issues.

- Generous draft angles (minimum radius of 5/64 in. [1.98 mm]) throughout the mold design will reduce tray fracture issues.
- To achieve acceptable finished part detail, vacuum channels should lead directly from the vacuum mold inlet to the vacuum holes on the corners of the mold. Vacuum channels should always be kept clean. Minimize the use of right angles in the vacuum system and piping to maximize vacuum speed. This will enable good contact between the plastic and the mold.
- To prevent excess bridging and flange thinning, use proper cavity spacing, especially on male molds. For every inch (25 mm) of depth into the mold cavity, there should be an inch of space between cavities.

*Note: Mold shrinkage will vary depending on the thermoforming process equipment but is typically 0.40% to 0.45% for Eastar™ copolyester and 0.65% to 0.75% for Eastman Tritan™ copolyester.*

### Thermoforming process

- Eastman recommends starting with quality Eastar 6763 and Tritan MP100 sheet. Quality sheet is characterized as having consistent gauge, low contamination, low cosmetic defects, and good inherent viscosity (i.e., molecular weight).
- Coatings or internal additives are often used to separate packages within a stack (i.e., denesting).
  - Silicone-coated sheet is often used to optimize denesting of packages. Eastman suggests using Dow Corning® 365 silicone emulsion.
  - When silicone coating is not permitted, an internal antiblock or denest concentrate can be added to Eastar or Tritan resin during extrusion. These are typically blended with Eastar or Tritan resin at a ratio of 50:1 to 100:1. Eastar additives cannot be used in products made of Tritan, and Tritan additives cannot be used in products made of Eastar.
  - With Tritan, the antiblock and denest concentrates must be specifically formulated for Tritan. These are typically blended with Tritan at a ratio of 20:1 to 10:1.
  - Contact your Eastman representative for more details.
- The mold surface should maintain a consistent temperature of 100°F (40°C) to 140°F (60°C) to prevent chill line formation or sticking.
- Heat settings on thermoforming equipment should be adjusted to produce the highest possible sheet temperature without sticking or bridging. For Eastar 6763, the optimum sheet temperature range for thermoforming, as measured by temperature-sensitive tapes, infrared thermometer, or

Eastman recommends following these tips to fully experience the benefits of easy thermoforming with Eastar™ 6763 copolyester and Eastman Tritan™ MP100 copolyester on a consistent basis.

handheld pyrometer, is 280°F (138°C) to 300°F (149°C). For Tritan MP100, the optimum sheet temperature range for thermoforming is 300°F (149°C) to 350°F (177°C). Higher sheet temperatures during thermoforming promote lower internal stress in the final packages. However, overheating film and sheet can cause the sheet to sag, resulting in bridging (webbing) in the final thermoformed package.

- As sheet temperatures increase, the plastic starts to sag, which will eventually cause bridging. Sag is the result of temperature and time in the oven. Higher sheet temperatures without additional sag can be obtained by
  - Decreasing cycle time and increasing oven temperature
  - Heating the sheet without using the full oven length and increasing temperature on the area closest to the mold. Note: Chain rails must be parallel for this setup.
- Two-sided heating may be required.
- For blank-fed male mold thermoforming machines, forming can be improved and bridging can be eliminated by using wire-helper grids.
- Internal stresses should be monitored using a polarized light table.

## Cutting sheet

Sharp, properly guarded, and well-maintained steel cutters are required for proper trimming of formed packages. A typical trimming press uses steel rule or matched metal dies.

### Steel rule die design

- Double-bevel measuring 3-point, 0.042 in. (1.07 mm) with a Rockwell C hardness of 45 to 55 is suggested.
- Blisters of Eastar 6763 and Tritan MP100 should be cut through completely when using steel rule cutting. The cutting stroke on the trim press should stop (i.e., fixed stroke) just after cutting through the blister. This is known as a “kiss” cut.
- Stainless steel striker plates 0.125 in. (3.2 mm) thick with an equivalent or slightly softer hardness than the die material is recommended.
- Heated steel rule knives can often improve the quality of the cut.
- Dies should have steel backup plates with a thickness of 0.030 in. (0.76 mm).
- Backup plates should be made of metal with a Rockwell C hardness of 30 to 35.

Match metal punches and dies should be properly maintained and have as close to zero tolerance as possible.

---

# EASTMAN

The results of insight™

## Eastman Corporate Headquarters

P.O. Box 431  
Kingsport, TN 37662-5280 U.S.A.

U.S.A. and Canada, 800-EASTMAN (800-327-8626)  
Other Locations, +(1) 423-229-2000

[www.eastman.com/locations](http://www.eastman.com/locations)

Safety Data Sheets providing safety precautions that should be observed when handling and storing Eastman Chemical Company (“Eastman”) products are available online or by request. You should obtain and review the available material safety information before handling any of these products. If any materials mentioned are not Eastman products, appropriate industrial hygiene and other safety precautions recommended by their manufacturers should be observed.

*It is the responsibility of the medical device manufacturer (“Manufacturer”) to determine the suitability of all component parts and raw materials, including any Eastman product, used in its final product to ensure safety and compliance with requirements of the United States Food and Drug Administration (FDA) or other international regulatory agencies.*

*Eastman products have not been designed for nor are they promoted for end uses that would be categorized either by the United States FDA or by the International Standards Organization (ISO) as implant devices. Eastman products are not intended for use in the following applications: (1) in any bodily implant applications for greater than 30 days, based on FDA-Modified ISO-10993, Part 1, “Biological Evaluation of Medical Devices” tests (including any cosmetic, reconstructive, or reproductive implant applications); (2) in any cardiac prosthetic device application, regardless of the length of time involved, including, without limitation, pacemaker leads and devices, artificial hearts, heart valves, intra-aortic balloons and control systems, and ventricular bypass assisted devices; or (3) as any critical component in any medical device that supports or sustains human life.*

*For manufacturers of medical devices, biological evaluation of medical devices is performed to determine the potential toxicity resulting from contact of the component materials of the device with the body. The ranges of tests under FDA-Modified ISO-10993, Part 1, “Biological Evaluation of Medical Devices” include cytotoxicity, sensitization, irritation or intracutaneous reactivity, systemic toxicity (acute), subchronic toxicity (subacute), implantation, and hemocompatibility. For Eastman products offered for the medical market, limited testing information is available on request. The Manufacturer of the medical device is responsible for the biological evaluation of the finished medical device.*

*The suitability of an Eastman product in a given end-use environment is dependent on various conditions including, without limitation, chemical compatibility, temperature, part design, sterilization method, residual stresses, and external loads. It is the responsibility of the Manufacturer to evaluate its final product under actual end-use requirements and to adequately advise and warn purchasers and users thereof.*

© 2018 Eastman. Eastman brands referenced herein are trademarks of Eastman or one of its subsidiaries or are being used under license. The ® symbol denotes registered trademark status in the U.S.; marks may also be registered internationally. Non-Eastman brands referenced herein are trademarks of their respective owners.